Thank you for your purchase of the Trick-Tools universal mounting plate! Here are a few tips that will make sure install goes quickly and easily.

- If you are using your mounting plate with the vise clamping block, you may need to install the 3/8 hex head bolts from bottom up during tool installation. This will allow sufficient clearance for vises with wider jaws.
- When installing Lancaster shrinker – stretchers, you'll use two washers under the head of each bolt to provide sufficient clearance for the shank of the bolt.

See the color coded guide below to aide in tool installation.



