



## **RAMS-2001 DRIVE CLEAT NOTCHER**

**Capacity 20 Ga. Mild Steel Maximum**

### **OPERATION:**

1. Mount the Drive Cleat Notcher to a secure solid work bench prior to use.
2. Adjust pins to outer location for drive cleats. Relocate pins to inner location for notching ends on hanger material.
3. After sliding in piece, pull down on spring loaded handle to notch.  
\*See product video for more information.

### **MAINTENANCE:**

1. Keep blades and pins free of debris.
2. Occasionally, put a light coat of oil on cutting blades and guide pins, to ensure efficient operation.
3. Shear blades are hardened, but may dull over time. Bottom blade can be turned over to use other side.

Distributed by: **Trick-Tools.com**



Trick-Tools  
80 Truman Road  
Pella, IA 50219

Phone: 1-877-VAN-SANT  
E-mail: sales@trick-tools.com

