



Distributed by: **Trick-Tools.com**

Trick-Tools
75 Truman Road
Pella, IA 50219

Phone: 1-877-VAN-SANT
E-mail: sales@trick-tools.com



Here at Trick Tools we believe that our customers deserve the best value in their tool and equipment purchases. We are constantly at work searching out a variety of high quality, high performance tools to offer at the best prices possible. Our commitment to you is that we will not offer "cheap junk" anywhere on our website. You, the customer, help us to evaluate our products constantly and as soon as an ongoing quality issue is uncovered we will correct it or discontinue that product immediately. We hope to earn your continued trust.



0500V26	1	*	GEAR BOX	
0510V26	1	*	GEAR BOX COVER	303243
0520V26	1	*	GEAR	
0521V26	1	*	GEAR	
0530V26	1	*	SCREW NUT	
0531V26	1	*	SCREW NUT	
0540V26	1	*	GEAR	303245
0550V26	1	*	GEAR SHAFT	
0560V26	1	*	SHAFT COVER	
0570V26	1	*	GEAR	303244
0580V26	1	*	MAIN SHAFT	
0591V26	1	*	MAIN SHAFT COVER	
0600V26	1	*	SPEED CHANGING SHAFT	
0610V26	1	*	SPEED CHANGING ARM	
0611V26	1	*	SHAFT STOPPER	
0612V26	1	*	SPRING	
0620V26	1	*	SLIDE BLOCK	
0630V26	1	*	CLUTCH	
0631V26	2	*	BRASS BRACKET	
0632V26	1	*	BRASS BRACKET	
G6008V	1	*	BALL BEARING	
G6206V	1	*	BALL BEARING	
G6303V	1	*	BALL BEARING	
G6304V	1	*	BALL BEARING	
L4030V	1	*	OIL SEAL	
L5230V	1	*	OIL SEAL	
L5840V	1	*	OIL SEAL	
CP0500V	1		GEAR BOX COMPLETE	303242
0700V26	1		SPEED CHANGING LEVER	
0740V26	1		SHAFT HOUSING	

1010V26	1	WORK TABLE
1020V26	1	TABLE SUPPORT FRAME
1080V26	2	BLADE GUARD

1311V26	1	GUIDE SUPPORT, UPPER
1312V26	1	GUIDE SUPPORT, LOWER
1320V26	4	BLADE GUIDE 303233
1331V26	1	BLADE STOPPER, LONG 303251
1332V26	1	BLADE STOPPER, SHORT 303263
1333V26	1	ECCENTRIC SHAFT
1350V26	1	BLADE GUIDE POST
1351V26	1	GEAR BAR
1360V26	1	GUIDE POST HOUSING
1370V26	1	BLADE GUARD, LEFT
1380V26	1	BLADE GUARD, RIGHT
1400V26	2	SPRING
1410V26	1	SPRING HOUSING
1440V26	1	POST HOUSING SPRING
1450V26	1	POST ELEVATING GEAR
1650V26	1	CIRCLE CUTTING ATTACHMENT
9015V26	1	GUIDE POST LOCK
9033V26	1	POST ELEVATE HANDWHEEL
9230V26	1	HANDLE KNOB
G6201V26	1	BALL BEARING

2000V26	1	MAIN DRIVE MOTOR 303255
2011V26	1	MOTOR PULLEY
2020V26	4	MOTOR ROTARY SEAT
BA43V26	2	V-BELT, 2011+7070
BA60V26	1	V-BELT, 2011+4450

3010V26	1	* LOWER WHEEL
3020V26	1	* RUBBER TIRE 303261
CP3010V26	1	LOWER WHEEL COMPLETE
3030V26	1	TAPER SLEEVE
3040V26	1	WHEEL LOCKING NUT
3020V26	1	* RUBBER TIRE
3050V26	1	* UPPER WHEEL
G6305V26	2	* BALL BEARING
CP3050V26	1	UPPER WHEEL COMPLETE
3060V26	1	UPPER WHEEL LOCK

WORK TABLE CONTINUED

1090V26	1	TABLE SUPPORT HOUSING
1100V26	1	GUIDE SUPPORT HOUSING
1120V26	1	RIGHT-HANDED SCREW
1140V26	1	LEFT-HANDED SCREW
1150V26	1	SLIDER
1160V26	1	TABLE TILT ADJUST SCREW
1500V26	1	METER GAUGE
1550V26	1	RIP FENCE + LOCK 303256
1800V26	1	FEED SCREW

WHEEL COMPONENT CONT.

3080V26	1 *	SLIDE BLOCK HOUSING
3090V26	1 *	SLIDE BLOCK SEAT
3100V26	2 *	SLIDE BLOCK GUIDE
3110AV26	1 *	UPPER WHEEL SLIDER
3116V26	1 *	SLIDER SCREW SHAFT
3120V26	1 *	WHEEL ELEVATE SHAFT
3121V26	1 *	SPRING
3150V26	1 *	WASHER
3180V26	3 *	INDICATOR RING
CP3080V26	1	SLIDE HOUSING COMPLETE
3190V26	1	TENSION INDICATOR
3200V26	1	WHEEL TILT ADJUSTER
3220V26	1	WHEEL TILT CONNECTER
3240V26	1	CONNECTER WASHER
3250V26	1	CONNECTER HOUSING
9030V26	1	HANDWHEEL
9060V26	1	TILT ADJUST HANDWHEEL

AIR PUMP COMPONENT

4060V26	2	AIR PUMP SEAT
4170V26	1	AIR NOZZLE
4180V26	1	AIR NOZZLE CLIPPER
4450V26	1	AIR COMPRESSOR 303229

VARIATOR COMPONENT

7000V26	1	MOTOR SPRING HOUSING
7010V26	1 *	SPRING
7020V26	1 *	VAEIATOR DISK, UPPER
7030V26	1 *	VAEIATOR DISK, UPPER
7040V26	1 *	VARIATOR HOUSING TUBE
7050V26	1 *	VARIATOR SHAFT
7060V26	1 *	VARIATOR HOUSING
G6007V26	1 *	BALL BEARING
G6205V26	2 *	BALL BEARING
CP7060V26	1	VARIATOR HOUSING
7070V26	1	PULLEY
7080V26	1	WORM GEAR
7090V26	1	WORM GEAR HOUSING
7100V26	1	GEAR SHAFT
7110V26	1	WORM
7120V26	1	WHIRLING ARM
7200V26	1 *	SPRING HOUSING
7210V26	1 *	SPRING
7220V26	1 *	VARIATOR DISK, LOWER
7230AV26	1 *	VARIATOR DISK, LOWER
7260V26	1 *	SHAFT HOUSING
G6007V26	1 *	BALL BEARING
G6204V26	1 *	BALL BEARING
CP7260V26	1	SHAFT HOUSING
7290V26	1	SPEED CHANGE WHEEL SEAT
7300V26	1	PULLEY

MAIN BODY & MISCELLANEOUS


5000V26	1	MAIN BODY
5100V26	1	REAR DOOR, LARGER
5101V26	1	REAR DOOR, SMALLER
5120V26	1	LOWER DOOR
5140V26	1	UPPER DOOR
8111V26	1	CONTROL PLATE
8372V26	1	VARIATOR INSTRUCTION
8422V26	1	GEAR BOX INSTRUCTION
8712V26	1	INDICATOR PLATE
8743V26	1	TILT INSTRUCTION
9300V26	2	UPPER DOOR HINGE
9310V26	6	HINGE
9500V26	4	SPRING PLATE
9590V26	2	HANDLE ARM

MAIN BODY & MISC. CONT.**VARIATOR COMPONENT CONT**

9600V26	1	CHIP STOPPER	7310V26	1	SPEED READOUT DETECTOR 303264
9700V26	1	INDICATE MIDDLE	7330V26	1	DIGITAL TACHOMETER 303238
9780V26	1	BRUSHER BRACKET	9030V26	1	HANDWHEEL
9790V26	1	CHIP BRUSHER 303237	BA44V26	-	V-BELT, 7071+7300 (60HZ)
9850V26	1	KEY FOR REAR DOOR	BA45V26	-	V-BELT, 7071+7300 (50HZ)
9880V26	1	CHIP COLLECTOR	BA43V26	-	V-BELT, 2011+7070
9900V26	1	MAGNIFYING GLASS	BV875V26	1	V-BELT

CONTROL SWITCH COMPONENT

6600V26	1	PUSH BUTTON, ON
6602V26	1	PUSH BUTTON, OFF,
6610V26	1	EMERGENCY SWITCH
6620V26	2	DOOR LIMIT SWITCH 303239
6650V26	1	KEY SWITCH
6700V26	1	MAIN POWER SWITCH
6713V26	2	MAGNETIC SWITCH 303254
6723V26	1	OVERLOAD STARTER 303258
6741V26	1	PILOT LAMP, GREEN
6745V6	1	VOLTAGE REDUCER 303266
6752V26	1	FUSE SEAT
6753V26	2	FUSE SEAT
6754V26	1	FUSE SEAT
6770V26	2	WIRE HOUSING
6771V26	1	GROUND SEAT
6798V26	1	ELECTRIC BOX
6799V26	1	WIRING PLATE



WELDER COMPONENT

6010V26	1 *	LIMIT SWITCH 303250
6011V26	1 *	INSULATOR
6020V26	1 *	GUIDE BLOCK
6040V26	1 *	HOUSING
6050V26	1 *	STATIONARY JAW
6051V26	1 *	INSULATOR
6052V26	3 *	INSULATING TUBE
6053V26	3 *	WASHER, INSULATE
6054V26	3 *	SPACER
6060V26	2 *	ECCENTRIC SHAFT
6070V26	1 *	CLAMP LEVER, RIGHT
6071V26	1 *	CLAMP LEVER, LEFT
6100V26	1 *	CLAMP SUPPORT, RIGHT
6101V26	1 *	CLAMP SUPPORT, LEFT
6110V26	1 *	CLAMP PLATE, RIGHT
6111V26	1 *	CLAMP PLATE, LEFT
6111V26	1 *	CLAMP PLATE, LEFT
6120V26	2 *	CAM
6130V26	1 *	MOVING JAW
6150V26	1 *	WELD BUTTON 303271
6160V26	1 *	MICRO SWITCH
6161V26	1 *	MICRO SWITCH BRACKET
6170V26	1 *	PRESSURE ADJUST KNOB
6180V26	1 *	SHAFT
6200V26	1 *	CAM
6210V26	1 *	WELD TENSION ARM
6211V26	1 *	BUSHING
6220V26	1 *	SPRING, SHORTER
6230V26	1 *	SPRING, LONGER
6240V26	1 *	TRANSFORMER (4.2KVA)
6241V26	1 *	MOUNTING BRACKET (4.2KVA ONLY)
6250V26	1 *	SWITCH
6260V26	1 *	GRINDER MOTOR
6270V26	1 *	SPACER
6280V26	1 *	GRINDER WHEEL 303248
6281V26	1 *	1/4" WASHER, FLAT
6282V26	1 *	6 mm-1.0 HEX NUT
6290V26	1 *	GRINDER GUARD 303247
6291V26	1 *	GRINDER COVER 303246
6330V26	1 *	WELDER NAME PLATE
6340V26	1 *	INSTRUCTION LABLE
6350V26	1 *	GRINDER LABLE
6420V26	1 *	ANNEAL BUTTON 303231
6450V26	1 *	DEFLECTOR BRACKET, RIGHT
6451V26	1 *	DEFLECTOR BRACKET, LEFT
6460V26	1 *	SPARK DEFLECTOR
9290V26	2 *	KNOB 303249
WCPV26	1	42-WELDER ASSEMBLY

WORK LAMP COMPONENT

6802V26	1 *	WORK LAMP COMPONENT 303272 Bulb MR 16 12v 20W
---------	-----	--

SHEAR COMPONENT

1910V26	3 *	SPINDLE BUSHING
1920V26	1 *	SPINDLE LIFT
1930V26	1 *	BLADE SHAFT
1940V26	2 *	VANED IRON PLATE
1950V26	2 *	LOWER BLADE
1960V26	1 *	UPPER BLADE
1970V26	1 *	JOINT PLATE, LEFT
1980V26	1 *	CHAIN JOINT, RIGHT
1990V26	1 *	HANDLE BAR
9210V26	1 *	KNOB
SCPV26	1	SHEAR COMPLETE 303234

