

HOW TO INSTALL THE EZ-SLIDE-IN TABLE

Before installing the EZ-SLIDE-IN TABLE, the shoe (located on the Milwaukee Deep-Cut Portable Band Saw), must be adjusted forward.

1. While pushing the button, located on the right side of the shoe, pull the shoe forward.



p

2. Tilt the EZ-SLIDE-IN TABLE up and line up the slit-opening with the blade.



3. Insert the shoe into the slot, located on the under-side of the EZ-SLIDE-IN TABLE.



4. Push the table back, until it stops.



5. Clamp the EZ-SLIDE-IN TABLE in place, by twisting the knob clockwise.



Trick-Tools.com

80 Truman Road

Pella, IA 50219

Phone:1-877-VAN-SANT

E-mail: sales@trick-tools.com



JSR Manufacturing, Incorporated is not responsible for any injury while using the EZ-SLIDE-IN TABLE

The EZ-SLIDE-IN TABLE by *JSR Manufacturing, incorporated* all rights reserved

Patent Pending filed with the United States Patent and Trademark Office: U.S. DEPARTMENT OF COMMERCE